

CARBURETED EVO PRESS FLYWHEEL KITS

Use on 1970 - 1984 Shovelhead or 1984 - 1999 Evolution These instruction are for the following part numbers: 1972,1973,1974,1976,1977,1978, 1979,1980,1981,1982,1983,1984,1985,1986,1987.

Read all instructions before performing any of this installation.

If you are not a qualified professional mechanic or equivalent, then do not attempt to perform this installation. You are responsible for the safety and quality of your work. If this installation is performed in an unsafe or unprofessional way, this could cause major damage or affect the safe operation of this motorcycle. Including but not limited to bodily injury or death. Take it to a qualified motorcycle repair shop if you are not sure.

The following are for Carbureted Evo Kits with piston sets:

No. 1976 - Use on 1984-99 Big Twin single cam motors. 4-1/4" Stroke x 8-1/2" O.D. With STD bore 3-1/2" pistons to build an 80".

The compression ratio is approximately 10:1; depending on the size of the combustion chamber in the heads being used and the thickness of both the head and base gaskets.

No.1977 - With +. 005 over size, 3-1/2" pistons, for above assembly.

No.1978 - With +. 010 over size, 3-1/2" pistons, for above assembly.

No.1979 - Use on 1984-99 Big Twin single cam motors. 4-1/2" Stroke x 8-1/2" O.D. With STD bore 3-1/2" pistons to build an 87".

The compression ratio is approximately 10:1; depending on the size of the combustion chamber in the heads being used and the thickness of both the head and base gaskets.

No.1980 - With +. 005 over size, 3-1/2" pistons, for above assembly.

No.1981 - With +. 010 over size, 3-1/2" pistons, for above assembly.

No.1982 - Use on 1984-99 Big Twin single cam motors. 4-5/8" Stroke x 8-1/2" O.D. With STD bore 3-1/2" pistons to build an 89".

The compression ratio is approximately 9.25:1; depending on the size of the combustion chamber in the heads being used and the thickness of both the head and base gaskets.

No.1983 - With +. 005 over size, 3-1/2" pistons, for above assembly.

No.1984 - With +. 010 over size, 3-1/2" pistons, for above assembly.

No. 1985 - Use on 1984-99 Big Twin single cam motors. 4-5/8" Stroke x 8-1/2" O.D.

With STD bore 3-5/8" pistons to build a 96".

The compression ratio is approximately 9.75:1; depending on the size of the combustion chamber in the heads being used and the thickness of both the head and base gaskets.

No. 1986 - With +. 005 over size, 3-5/8" pistons, for above assembly.

No.1987 - With +. 010 over size, 3-5/8" pistons, for above assembly.

NOTE: All flywheel kits with or without pistons use a .792" I.D. wrist pin bushing.



NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



Below is the list of Stroker Flywheel Assemblies Only (without pistons):

The engine builder must supply the pistons that go with the flywheels. If installing in a 1970 to 1972 motor, the engine builder will need to replace the side-oiling pinion shaft bushing in the cam cover with JIMS No.25582-80AB. You may also need to do some modification to the cam cover to use the new end-oiling bushing. The new bushing will need to be line reamed with Jims tool No.94805-57, see JIMS catalog for other tools for removing and installing bushing.


No.**1972** - Use on 1970-99 Big Twin single cam motors, 4-1/4" Stroke x 8-1/2" O.D. No.**1973** - Use on 1970-99 Big Twin single cam motors, 4-1/2" Stroke x 8-1/2" O.D. No.**1974**- Use on 1970-99 Big Twin single cam motors, 4-5/8" Stroke x 8-1/2" O.D.

Piston Weight Requirements for JIMS Flywheel Assemblies

Below is a list of total piston weights. Example: 906 grams to 938 grams is the weight of two pistons, two sets of rings, two wrist pins and four wrist pin clips.

If the total weight of the pistons you are supplying weigh from 906 to 938 grams, they can be used with any of the three flywheel assemblies listed above to give you a balance factor of approximately 60%.

An approximate 60% balance factor is best suited for higher RPM riding (shifting at a higher RPM) or a lower gear ratio. An approximate 52% balance factor is best suited for a little lower RPM riding, or a little higher gear ratio.



To maintain a balance factor of approximately 56%, both pistons with rings, pins, and clips should weigh between 1021 grams and 1051 grams.

To maintain a balance factor of approximately 52%, both pistons with rings, pins, and clips should weigh between 1136 grams and 1166 grams.



Recommended Tools

JIMS Part No.	Description
No.1276	Wrist Pin Remover/ Installer
No.1047TP	Crank Assembly Removing Tool, for F/W removal
No.1048	Hard Cap, use with No.1047TP
No.39361-69	Motor Sprocket Seal Installer Tool
No.1710	Snap Ring Installer and Removal Tool
No.1745	Timken Bearing Simulator
No.97225-55	Sprocket Shaft Bearing Installation Tool
No.1709	Timken Bearing Remover Tool
No.1034	Sprocket Shaft Holder
No.1006T	Engine Stand
No.1236	Piston Ring Compressor Tool
No.1409	Case Boring Tool (for 3-5/8" to 3-13/16" bore cylinders)
No.96710-TL	Lap Tool, right case race
	Degree Wheel for timing breather valve & crankshaft endplay
	Ratcheting Snap Ring Pliers



NOTE: Please read this entire instruction sheet before and during the installation of these flywheels and pistons.

NOTE: You must use a H-D® Service Manual for the installation of these flywheels.

WARNING: The rider's safety depends on you performing this installation correctly.

WARNING: Always disconnect the ground (negative) cable at the battery, by not doing so could result in death or serious personal injury.

WARNING: Always wear safety glasses over your eyes; always protect your hands and face when using any cleaning materials.

WARNING: Gasoline is highly flammable and explosive; don't smoke or have any open flames near any flammable liquids.

JIMS is proud to introduce these improved Big Twin flywheels. These flywheels are not just a copycat flywheel with a different stroke, but a flywheel redesigned and engineered for today's Harley-Davidson® Motorcycles.

JIMS Big Twin flywheels are manufactured from the finest American 4140 forged steel blanks; ideal for precision machining and product integrity. To further help in rod strength and lubrication, we have designed three grooves around both crankpin thrust faces of these JIMS flywheels. With grooves machined into the flywheel thrust faces, we have eliminated the four grooves that are machined into the rod itself. When grooves are machined into the connecting rod, the rod becomes susceptible to cracking.

JIMS CONNECTING RODS ARE PRODUCED FROM FORGED 4340 AEROSPACE QUALITY STEEL.

Connecting rods at their finest. JIMS research and development team looked into all other rods on the market to see which areas needed improvement. JIMS connecting rods start out as forged aerospace quality 4340 Chromoly steel blanks, and then are CNC machined on the newest high tech mills available. Each rod is heat-treated, magnafluxed, shot peened, and completely inspected with a hardness test. From there, each rod goes back into the CNC mill to machine the rod race bores to the wrist pin bores to within .0003" of each other at a 32 micron finish for the best possible bushing and race adhesion. The wrist pin bushing oiling hole has been optimized for better lubrication of wrist pins, and increased strength. JIMS chose "H-Beam" rods for stability and strength, for both drag racing and street applications, over the standard "I-beam" rods. Although we realize that "H-beam" rods



are very difficult and time consuming to manufacture, JIMS believes it is well worth the extra effort. Each rod set has JIMS rod races and wrist pin bushings installed and are fit to Harley-Davidson factory specifications.

JIMS has provided you with detailed information listing the applications and specifications of each JIMS stroker kit applicable to this instruction sheet. Please refer to this information throughout your installation for critical component combinations and specifications. Do not attempt to install your stroker kit without cross checking each component for compatibility.

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



For engine removal follow the instructions in H-D Service Manual.

Follow the disassembly instructions in the service manual to disassemble engine. Clean all parts thoroughly; make sure to clean all gasket and mounting surfaces. Inspect all parts for visible damage. Measure all parts for wear using the service wear limits in the H-D Service Manual. Check and repair all threaded holes. Replace or repair all worn or damaged parts with JIMS engine parts or equivalent.

Pinion Side Fitment.

These kits are shipped with standard length sprocket and pinion shaft (pinion shaft similar to Jims No.2437,) to be installed into 1970-1999 cases with standard pinion shaft races. JIMS No.24628-87 Green size pinion bearing may also be used, see JIMS catalog for other over size pinion shaft bearing sets. Use JIMS No.2481K pinion bearing retainer.

Note: Follow your H-D Service Manual for fitment of pinion bearings.

Use Jims tool No.96710-TL to lap pinion race to fit pinion bearing.

For 3-5/8" to 3-13/16" bore pistons and cylinders, you will need to bore the engine cases to accept the bigger cylinders. Use JIMS No.1409 Case Boring Tool (for 3-5/8" to 3-13/16" bore cylinders.)

For 1990-99 motors, use JIMS pinion gear No.24043-78, JIMS oil pump drive gear No.26349-84 (with JIMS keys 2480), JIMS nut No. 24023-54, and JIMS No. 24703-54b pinion gear spacer.

For these flywheel assemblies, you will need to use JIMS pinion gear No.24043-78 as a starting point for cam gear to pinion gear fit.

Instructions: Preparing the engine cases for JIMS flywheels.


1. Check cylinder studs and deck surfaces for flatness and any imperfections:

Clean and wash cases. Give special attention to the cases mating surfaces and assemble without flywheels. Install and torque all case bolts to H-D Service Manuals specs.

Note: Take a measurement of stud height before removing. Caution: Some studs may need heat to remove, do not over heat, 210 degrees max.

Check cylinder base gasket surface. Use a straight edge across the deck. **See Fig 1.** If any misalignment is present, the surface must be milled.

Cover all areas where filings could get into. Take off just enough case material to clean up the surface. Check all cylinder studs and threaded holes. If threads are damaged use JIMS tool No.1000A to repair. JIMS suggests using the latest cylinder studs available from Harley-Davidson, No.16837-85C. Follow instructions in H-D Service Manual for proper installation of studs.



2. Checking flywheel to inner case clearance.

All JIMS flywheels must be checked for having a clearance of no less than .060" to the inside of the left and right engine case halves. With the old or new Timken bearing races installed in the left case and a new Timken bearing installed on sprocket shaft, use JIMS tool No.97225-55 following your H-D service manual, and install the bearing on the new flywheel assembly. With small pieces of modeling clay pressed over any and all high places on the inside of left case (modeling clay needs be at least .100" thick.) See Fig 2, next page.

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



Do not rotate the flywheels when performing this clay


check. Place the flywheel into the left case and hold in place with JIMS No.1745 Timken Bearing Simulator. With small pieces of modeling clay pressed over any and all high places on the inside of right case (modeling clay needs be at least .100" thick.)

Install old or new pinion bearing on pinion shaft and install the right case over the flywheels and up to left case.

Note: You can use your old pinion shaft bearings for this clearance check; if you have already fit oversized pinion bearings, you may use them if the case race has been completely cleaned of all lapping compound. Do not rotate the flywheels when performing this step.

Install and tighten at least 3 lubricated case bolts to 10 ft/lbs. Gently remove case bolts and remove the right case from over the flywheels. Remove the flywheels from the left case.

Check the compressed clay pieces for having no less then .060" thickness at any location.



If one or more of the compressed clay pieces is less than .060" thick, you'll need to remove case material from the areas to maintain .060" clearance.

Example: If you measure .040", you will need to remove approximately .020" of case material.

Remember to remove only enough material to maintain .060" of flywheel to case clearance.

Caution: A minimum of .060" clearance is required. Be sure to mask off all bearing bores, oil holes and threaded holes, before any case material is removed.

Do not remove any material from flywheels, shafts, bearings or rods.

If you are unsure as to whether or not you have at least .060" clearance, repeat the above clearance check until you are sure of the clearance for all of the high areas in both case halves.

3. Connecting rod to case clearance.

To accurately check the necessary rod to case clearance, you will need to mock up the flywheel assembly into the left side case by using JIMS No.1745 Timken Bearing Simulator, same as above.

Note: Fitting pistons to cylinders for a running clearance will need to be completed before the rod to case clearance check can be performed.

The pistons in this kit need to be fit to the cylinders using the specifications provided with pistons.

Note: Make sure cylinders have been washed, before installing pistons when checking rod clearance.

With flywheel assembly simulated in left case, (using JIMS No.1745 Timken Bearing Simulator) install pistons without rings and place both cylinders on left case with 2 nuts and a short piece of rubber hose to hold cylinders down. Base gaskets are not needed for this test.

Apply clay here

FIG 2

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



Instruction Sheet for Carbureted EVO Press Flywheel Kits

Note: Apply a small amount of lube (assembly oil or motor oil) to piston skirts before installing in a clean and dry cylinder.

Note: You may install one of the pistons wrist pin locks in each piston to hold the wrist pin from falling out.

Caution: Make sure pistons are installed properly. The beveled cut out on the cylinder spigot must point towards (face each other) the center of the engine. **Note:** Some JIMS piston sets are directional. Please align engraved (or laser marked) arrow on piston crown (top of piston) to the intake valve unless otherwise noted. If using pistons other than JIMS, consult piston manufacturer's installation instructions for proper alignment.

Rotate flywheels slowly, first clockwise watching for the rods or pistons making contact with each other or any part of the cases, see Fig 3. With felt pen, mark the point of contact that rod makes at case (Note: if rod makes contact with cylinder spigot first, mark point of contact of rod to spigot with felt pen).

Caution: Before removing any material remove flywheel assembly and cover to keep out all debris and also mask all bearing bores, oil holes and threaded holes of both cases.

Grind and file cylinder for a minimum of .100 \pm .025, rod clearance.





Caution: When grinding and filing cylinder, you must maintain a smooth finish, without leaving sharp edges.

Rotate flywheels counterclockwise, see Fig 4. With felt pen mark the point of contact the rod first makes at case. With a straight edge mark a line from the marked point of rod contact to the other marked point of rod contact. With your calipers set at .100, mark a line to the outside of the first line. This is the area you will be removing for rod clearance. Note: This .100 line is added in for the necessary rod to the case clearance. Do the front rod clearance the same way. Caution: Before removing any material remove flywheel assembly and cover. Also mask off all bearing bores, oil holes and threaded holes of both cases. After you have rechecked clearance of the left case (for the necessary .100 rod to case clearance) and cylinder spigots, remove cylinders, pistons and flywheels from left case. Mark and remove material from right case to match left case. Caution: Before removing any material remove flywheel assembly, cover and mask all bearing bores, oil holes, and threaded holes of both cases. Recheck your clearance for right case by installing flywheels, both cylinders and pistons.

4. Piston to piston and piston's skirt to flywheel clearance.

With the flywheel assembly mocked up in left case only, install cylinders and pistons, (no rings on the pistons as before). Make sure they are installed properly. The beveled cut away on the cylinder base points towards the center of the engine. Securely install the cylinders with (2) nuts on each cylinder. Rotate flywheel assembly slowly until pistons make contact with each other (or just start to pass by each other.) See fig 5. A minimum of .100" clearance is required for the pistons to clear each other.

Note: All material removal to be done on the rear intake side of piston only.

Caution: When grinding and filing the rear piston you must maintain a smooth finish without leaving sharp edges.

Remove only enough to make the .100" clearance. After piston-to-piston clearance is performed rotate flywheel and check piston to flywheel clearance. Remove piston and or pistons and clearance skirt to a .100" minimum clearance. See fig 6.

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



5. Piston deck height

With flywheel assembly mocked up in left case, install base gaskets, pistons (no rings or wrist pin clips), and cylinders. Secure to cylinders as stated previously.

Rotate flywheel assembly so the front piston is at its highest point of travel (TDC). Using a straight edge laying across the bore diameter (top of cylinder) measure (using a feeler gauge) the distance from the piston top to the cylinder head gasket surface. (Note: If the piston is higher than the gasket surface, this is referred to as "Positive Deck Height", if the piston is below the head gasket surface, this is referred to as "Negative Deck Height", note this measurement.) Now measure the thickness of your head gasket using dial calipers or a micrometer and subtract your deck height measurement from your head gasket thickness. You must have a minimum of .043" clearance between your piston top and the top of the head gasket when it is installed on the cylinder. If you have too little deck height (less than .043") you can adjust this by using a thicker base or head gasket. Remember optimal range for a performance oriented street motor is .043" to .060" of deck below the top of the head gasket.



JIMS recommends checking the breather timing on all engines regardless of the stroke. Optimized breather timing will maximize performance. This procedure requires a degree wheel. When modifying the breather hole in the case, make sure the breather hole in the case is located in the same position as hole in the breather. See Fig 7.


Caution: Before doing any grinding, mask off and cover all areas to keep out foreign material. Grind the case breather opening to the specifications below:


Opening - 0 degrees @ TDC \pm 10 degrees with minimum being 10 degrees before top dead center and maximum being 10 degrees after top dead center.


Closing - 65 degrees @ ABDC \pm 10 degrees with minimum being 55 degrees after bottom dead center and with maximum being 75 degrees after bottom dead center.

7. Ignition timing

Before installing the flywheel into the case, put a paint dot or white out on the front cylinder TDC (0°) and front advance marks (34.5°). If you are using an electronic advance ignition, follow the instructions from the manufacturer for static timing. If you are using a mechanical advance ignition, you will have to use a strobe timing light and sight the advance mark through the timing plug hole. Follow H-D service manual guidelines for points ignition or directions from the ignition manufacturer.







NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



8. Final assembly.

Be sure all the work you have performed from the above instructions is correct before final assembly of the engine. Assemble engine per **H-D Service Manual**. Make sure all parts are cleaned and checked for being in good working order. Before installing your newly rebuilt engine, remove oil tank, oil lines and oil cooler. Wash out all these parts until you can run a clean cloth inside the oil tank and it comes out clean.

After you have installed this newly rebuilt engine and hooked up all the oil lines except the return oil, fill oil tank with proper grade and amount of oil.

Direct the oil return line into a catch-pan that can hold 2 to 3 qts of oil. Remove the spark plugs, attach the plug wires to the spark plugs, ground spark plugs on the cylinder heads, and turn over the engine until the oil pressure light goes out or you have 10 –15 psi.

Install spark plugs and wires, start engine allowing the return oil to run into catch–pan. Run engine at 1000 to 1500 RPM (do not blip the throttle) until the tops of cylinders reach 200 degrees Fahrenheit (too hot to touch at the top of cylinders, **not the heads**) this normally takes between one and two minutes, depending on air temperature.

Note: Do not let the oil level in oil tank get lower than 3/4 of a quart, while the engine is running.

Stop the engine and let it cool to ambient temperature. Check for any oil or gas leaks and top-off oil tank. Repeat the warm up and cool-down procedure three additional times.

Note: Do not let the oil level in oil tank get lower than 3/4 of a quart, while the engine is running.

You may now reconnect the return oil line to oil tank after at least two quarts have been pumped into the catch-pan.

Caution: If you do not perform the above initial start up procedure to seat head gaskets for the first time, this will often cause premature head gasket failure.

These break in instructions may take a little more time now, but it is less time than replacing damaged parts from improper start ups.

Note: Damage resulting from improper break in is not covered under any warranty. Only you are responsible for the quality of the job you perform. JIMS cannot be liable for inexperienced workmanship.

9. Break in Procedure for the first 2000 miles.

- 1. Allow the engine to warm-up before riding (about 200 degrees at the top of cylinders.)
- 2. Do not allow the engine to idle any lower than 1000 rpm and do not rev engine any more than 1500 rpm upon any cold start up.
- 3. Do not use full throttle and do not blip the throttle at any time during the break in.
- 4. Do not idle the engine for more than two minutes, (less time if air temp is above 80-degrees)
- 5. Do not load or lug the engine at any time. (especially at low RPM)
- 6. Vary the RPM at least every two minutes. (do not hold a steady speed)
- 7. Use common sense when running a new engine, NO burn-outs, No wheelies, No running the engine without it being in perfect-tune. You may see those morons on TV doing it, but you'll never see that bike running again.
- 8. Follow H-D Service Manual for all maintenance information as you continue to put miles on this engine.
- 9. First 50 miles.
 - a. Do not rev the engine more than 2500 rpm
 - b. Do not exceed 50 MPH
 - c. Change the oil and filter
 - d. See re-torque Notes and Cautions below
- 10. Next 500 miles
 - a. Do not rev the engine more than 3000 rpm
 - b. Do not exceed 55 MPH.
 - c. Change the oil and filter
 - d. See re-torque Notes and Cautions below

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.



- 11. Next 1000 miles
 - a. Do not rev the engine more than 4000 rpm
 - b. Do not exceed 65 MPH
 - c. Change the oil and filter
 - d. Continue to vary the RPM at least every two minutes, (do not hold a steady speed)
 - e. See re-torque Notes and Cautions below
- 12. Next 1500 to 2000 miles
 - a. Do not rev the engine more than 4000 rpm
 - b. Do not exceed 65 MPH
 - c. Change the oil and filter
 - d. Continue to vary the RPM at least every two minutes, (do not hold a steady speed)
 - e. See re-torque Notes and Cautions below
- 13. Re-torque fasteners

Note: Re-torque, Re-check the torque on all engine and chassis fasteners at each oil and filter change.

Caution: Do not re-torque head bolts on EVO engines. If the engine is a Shovelhead, re-torquing the head bolts and base nuts will need to be performed after the first running and cool down of engine.

Note: Only re-torque head bolts and base nuts after the engine has cooled down after running, the re-torque should be per formed two to three times in the first 50 miles until the bolts or nuts do not move under the maximum torque setting.

JIMS Thanks you for using the best, and have fun.

JIMS® IS NOT RESPONSIBLE FOR THE QUALITY AND SAFETY OF YOUR WORK!

If you are not sure about any of the procedures in these instructions, have a reputable H-D® repair shop perform these procedures for you.

WARNING: Always disconnect the Battery Ground Cable (at the battery) to prevent injury. Your work area should be well lit. Wear safety glasses (over your eyes) and protective clothing when working around power tools and compressed air. Be careful with chemicals when cleaning parts. Protect your skin from solvents and use only in a well-ventilated area. Degreasers are flammable and are a fire hazard. Just use common sense and exercise good judgement.

NOTE: THE ENGINE BUILDER STILL HAS THE RESPONSIBILITY OF CHECKING AND CONFIRMING ALL OPERATING CLEARANCES WHEN INSTALLING ANY JIMS® PARTS.