



A Division of Thiessen Products, Inc.

## INSTRUCTION SHEET FOR TOOL #1707

### SPREADING TOOL

USE ON ALL 1980-2001 RUBBER MOUNT BIG TWIN, EXCEPT DYNAS



1. Refer to H-D® Service Manual for specifications.
2. Install cleverbloc spreading tool between swing arm cleverblocs. Lube all threads.
3. Turn nuts with a 3/4" wrench to spread the cleverblocs apart to approximately 4.600 inch.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL.  
SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.  
THE LAST TOOLS YOU WILL EVER NEED TO BUY.

*"Doing It Right...The JIMS Way!"*

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224



A Division of Thiessen Products, Inc.

## INSTRUCTION SHEET FOR TOOL #1707

### SPREADING TOOL

USE ON ALL 1980-2001 RUBBER MOUNT BIG TWIN, EXCEPT DYNAS



1. Refer to H-D® Service Manual for specifications.
2. Install cleverbloc spreading tool between swing arm cleverblocs. Lube all threads.
3. Turn nuts with a 3/4" wrench to spread the cleverblocs apart to approximately 4.600 inch.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL.  
SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.  
THE LAST TOOLS YOU WILL EVER NEED TO BUY.

*"Doing It Right...The JIMS Way!"*

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224