



INSTRUCTION SHEET FOR #1055

VALVE GUIDE GAUGES - HOLDER ONLY



PIN BUSHING

Use to hold JIMS® gauge pins #2149-2160, to check valve guide clearance on all guides.

1. Refer to Harley Davidson® Service Manual for specifications.
2. Loosen nuts on both sides of holder. Install the appropriate size pins with bushing installed as shown above and tighten nuts to hold in tool (lightly). Correct bushing supplied with each gauge pin.
3. Lube pins lightly before and after checking guide bores.


**CAUTION: WEAR SAFETY GLASSES, EXCESSIVE FORCE MAY DAMAGE PARTS OR TOOLS.
SEE JIMS® TOOL CATALOG FOR OVER 100 TOP QUALITY PROFESSIONAL TOOLS.**

555 DAWSON DRIVE, CAMARILLO, CA 93012
PHONE 805-482-6913 • FAX 805-482-7422



INSTRUCTION SHEET FOR #1055

VALVE GUIDE GAUGES - HOLDER ONLY



PIN BUSHING

Use to hold JIMS® gauge pins #2149-2160, to check valve guide clearance on all guides.

1. Refer to Harley Davidson® Service Manual for specifications.
2. Loosen nuts on both sides of holder. Install the appropriate size pins with bushing installed as shown above and tighten nuts to hold in tool (lightly). Correct bushing supplied with each gauge pin.
3. Lube pins lightly before and after checking guide bores.

**CAUTION: WEAR SAFETY GLASSES, EXCESSIVE FORCE MAY DAMAGE PARTS OR TOOLS.
SEE JIMS® TOOL CATALOG FOR OVER 100 TOP QUALITY PROFESSIONAL TOOLS.**

555 DAWSON DRIVE, CAMARILLO, CA 93012
PHONE 805-482-6913 • FAX 805-482-7422