

INSTRUCTION SHEET FOR #2122A

RECEPTACLE EXTRACTOR - USE ON ALL MODELS



- 1. Disconnect electrical plug and battery. Refer to H.D. Service Manual for specifications.
- 2. While holding plug, firmly push wire toward the receptacle to be removed.
- 3. While holding wire slide outer sleeve of extractor down onto receptacle until it firmly bottoms.
- 4. While holding plug slowly rotate receptacle remover in a circular motion while pushing down firmly on extractor button.
- 5. Remove receptacle from plug.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-7422

No.2122-IS



REV NC 11/97

INSTRUCTION SHEET FOR #2122A

RECEPTACLE EXTRACTOR - USE ON ALL MODELS



- 1. Disconnect electrical plug and battery. Refer to H.D. Service Manual for specifications.
- 2. While holding plug, firmly push wire toward the receptacle to be removed.
- 3. While holding wire slide outer sleeve of extractor down onto receptacle until it firmly bottoms.
- 4. While holding plug slowly rotate receptacle remover in a circular motion while pushing down firmly on extractor button.
- 5. Remove receptacle from plug.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.