




## Instruction Sheet For #33071-73

### Wheel Bearing Race Remover and Installer Tool

Use on Big Twin and Sportster - 1973-Present



1. Refer to H.D.® service manual for specifications.  
Use to remove and install bearing cups in cast wheels  
(Use with JIMS tool handle #33416-80).  
(Use a press fit lube, like JIMS® #2124)  
If a press is not available it is highly recommended that  
you use a brass hammer.

**CAUTION:** Wear safety glasses. Excessive force may damage parts! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

*"From the Track... To the Street!"*


555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422



## Instruction Sheet For #33071-73

### Wheel Bearing Race Remover and Installer Tool

Use on Big Twin and Sportster - 1973-Present



1. Refer to H.D.® service manual for specifications.  
Use to remove and install bearing cups in cast wheels  
(Use with JIMS tool handle #33416-80).  
(Use a press fit lube, like JIMS® #2124)  
If a press is not available it is highly recommended that  
you use a brass hammer.

**CAUTION:** Wear safety glasses. Excessive force may damage bearings! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

*"FROM THE TRACK... TO THE STREET!"*

555 Dawson Drive, Camarillo, CA 93012 Phone 805-482-6913 • Fax 805-482-7422 • www.jimsusa.com