

INSTRUCTION SHEET FOR PART NO. 7999, 7999P, 7999B



TRANSMISSION CASE BIG TWIN-FXST TO 1990-1999

This case will accept JIMS® 5-speed or 6-speed gears and shafts.

It also accepts H-D[®], or after market gears and shafts.

On earlier FXST models, inner primary cover, side cover, starter, etc may need upgrade to match later transmission case.

Please refer to H-D Service Manual for proper procedure of assembling & disassembling transmissions.

JIMS® offers many tools for transmission tear down and assembly from the clutch area, pulley lockers, seal, and bearing installers, etc.

The following is a list of tools from JIMS® that work on FXST transmission related work:

No.**2316** Primary Locking Bar

No.38515-90 Clutch Spring Compressor (90-97)

No.34902-84 Mainshaft Bearing Race Tool

No.94660-37A Mainshaft Sprocket Lock nut Wrench

No.2260 Sprocket Locker

No.2256 Main Drive Gear Seal Installer
No.95660-85 Main Drive Gear Seal Installer
No.37842-91 Main Drive Gear Bearing Tool

No.1720 Main Bearing Remover

No.35316-80 Main Drive Gear Bearing Tool

No.1078 Transmission Cover Bearing Remover & Installer

No.2189 Transmission Shaft Installer

No.2283 Door Puller

No.2362 External Lock Ring Pliers

No.1008-TS Transmission Stand

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL.

SEE JIMS® CATALOG FOR OVER 200 OTHER TOP QUALITY PROFESSIONAL TOOLS.

THE LAST TOOLS YOU WILL EVER NEED TO BUY.