

INSTRUCTION SHEET FOR TOOL NO.94547-80A AND NO.94547-80B



SPROCKET SHAFT BEARING RACE REMOVER AND INSTALLER

USE TO REMOVE AND INSTALL BEARING CUPS IN MOTOR CASE

USE WITH JIMS® TOOL HANDLE NO.33416-80

94547-80A - USE ON 1969-2002 BIG TWIN

94547-80B - USE ON 1977-2003 SPORTSTER AND 1987-2003 BUELL

Refer to H.D.® Service Manual for specifications.

- 1. Place tool into bearing cup, one half at a time. (Support the case around the bearing bore, when removing or installing races.)
- 2. Insert handle into the center of the two drivers. Press out the races one at a time.
- 3. When installing the race (support the case squarely) use a press fit lube, install races one at
- 4. Insert handle into the center of the two drivers, press race in until it stops on snap ring.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE BEARINGS!
SEE JIMS CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-7422

No.94547-is



REV C 4/12

a time.

Instruction Sheet For Tool No.94547-80A and No.94547-80B



SPROCKET SHAFT BEARING RACE REMOVER AND INSTALLER

USE TO REMOVE AND INSTALL BEARING CUPS IN MOTOR CASE

USE WITH JIMS® TOOL HANDLE NO.33416-80

94547-80A - USE ON 1969-PRESENT BIG TWIN

94547-80B - USE ON 1977-PRESENT SPORTSTER

Refer to H.D.® Service Manual for specifications.

- 1. Place tool into bearing cup, one half at a time. (Support the case around the bearing bore, when removing or installing races.)
- 2. Insert handle into the center of the two drivers. Press out the races one at a time.
- 3. When installing the race (support the case squarely) use a press fit lube, install races one at

a time.

4. Insert handle into the center of the two drivers, press race in until it stops on snap ring.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE BEARINGS!
SEE JIMS CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.