

Instruction Sheet For No.18607-57a & No.18607-57AC

Sportster Tappet Guide Use on Sportster 1957-85



Please read all instructions thoroughly before starting work. Refer to H.D[®] Service Manual for specifications.

- Make sure bike cannot start by removing ground wire from frame. Have a clean working environment including clean rags, clean engine and a place to set everything.
- 2. If not already done, remove old blocks and tappets using JIMS® puller No.95724-57.
- 3. Keep all foreign material out of tappet block holes.
- 4. Wash pushrods and pushrod covers, install new seals.
- 5. NOTE: These blocks are designed to accommodate a stock lift. But still check the clearance. You will need at least 035 roller to block clearance with any cam being used. To check for this do the following: With tappet in rear block, no o-ring, one tappet at a time, Cam lobe for the one that you are checking at the highest point of lift. Slide the assembly into the motor (NOTE: If the tappet block flange does not touch the motor case during this trial assembly, remove material as needed to give the necessary .035" of up and down tappet movement). With assembly still in motor snug, screw to about 30 in. Ibs. Now check for .035" free movement. Do the same for the other tappets. If more clearance is needed remove the least amount of material from the tappet blocks as needed. (NOTE: Make sure to remove any burrs after modifying the blocks, wash and dry).
- 6. Apply a light film of motor oil or sealer to o-ring, install on blocks. Apply assembly lube to tappets and rollers. Slip tappets into blocks, you can hold tappets in place with your fingers.
- 7. With all blocks in place (NOTE: Putting all blocks into motor case will keep the screws from falling into case), tighten to H.D.® specifications.

CAUTION: Wear safety glasses. Excessive force may damage parts! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

"From the Track... To the Street!" 555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422